




dryer
DI 225

Parts Manual



Revision 2.0
30 / 06 / 2004



Parts List

Item	Part No.	Qty.	Description
1	A0-E006-001	1	Control Transformer
2	A0-E021-046	3	Terminal
3	A0-E004-002	3	Magnetic Contactor
4	A0-E004-011	2	Magnetic Contactor
5	A0-E025-025	1	Over Load
6	A0-E025-004	1	Over load
7	A0-E031-009	2	Timer Coil

Parts List

Item	Part No.	Qty.	Description
8	A0-E051-012	2	Fuse 4A
	A0-E051-007	1	Fuse 6A
9	A0-E050-001	1	Bridge rectifier
10	A0-E031-019	1	Rotation Watchdog Timer
11	A0-E009-001	2	Relay
12	A0-E024-005	1	Auxiliary contact
13	A0-E021-045	8	Terminal
14	A0-E021-044	5	Terminal
15	A0-E021-043	41	Terminal



Parts List

Item	Part No.	Qty.	Description
1	A0-A013-002	1	Lock, control panel assembly, right
2	A2-S225-001	1	Front panel assembly, top
3	A2-S225-002	1	Front top panel assembly, door

Parts List

Item	Part No.	Qty.	Description
4	A2-S225-003	1	Door ring, right
5	A2-S225-004	1	Door ring, left
6	A2-S225-005	1	Control panel assembly, right
7	A2-S225-006	1	Control panel assembly, left
8	A2-S225-007	1	Door dryer, right
9	A2-S225-008	1	Door dryer, left
10	A2-S225-009	1	Front lower panel assembly, door
11	A2-S225-010	1	Front panel assembly, lower-right
12	A2-S225-011	1	Front panel assembly, lower-Left
13	A2-S225-012	1	Lower panel assembly, left
14	A2-S225-013	1	Left middle panel assembly, right
15	A2-S225-014	1	Left middle panel assembly, left
16	A2-S225-015	1	Top panel assembly, left
17	A2-S225-016	1	Top cover assembly, left
18	A0-A003-012	1	Door glass, right
19	A0-A003-012	1	Door glass, left
20	A2-S225-017	1	Panel, safety Guard door lint drawer filter
21	A2-S225-018	1	Door lint drawer filter
22	A0-A013-002	2	Lock, left middle panel assembly, right
23	A0-A013-002	2	Lock, left middle panel assembly, left
24	A0-A013-002	1	Lock, control panel assembly, left
25	A2-S225-024	1	Panel, safety Guard, left Lower




Parts List

Item	Part No.	Qty.	Description
1	A2-S225-019	1	Top cover assembly, right
2	A2-S225-020	1	Top panel assembly, right
3	A2-S225-021	1	Right middle panel assembly, right
4	A2-S225-022	1	Right middle panel assembly, left
5	A2-S225-023	1	Lower panel assembly, right
6	A2-S225-025	1	Panel, safety Guard, right lower (Motor)
7	A0-A013-002	2	Lock, right middle panel assembly, right
8	A0-A013-002	2	Lock, right middle panel assembly, left
9	A2-S225-026	1	Panel, Safety Guard, font lower




Parts List

Item	Part No.	Qty.	Description
1	A2-S225-025	1	Panel, safety Guard, right lower (Motor)
2	A2-S225-027	1	Wheel rubber box, top
3	A2-S225-028	1	Rear panel assembly, top
4	A2-S225-029	1	Rear panel assembly, middle
5	A2-S225-030	1	Rear panel assembly, middle
6	A2-S225-027	1	Wheel rubber box, lower
7	A2-S225-031	1	Rear panel assembly, lower
8	A2-S225-032	1	Panel, safety Guard, rear lower
9	A2-S225-033	1	Exhaust duct



Parts List

Item	Part No.	Qty.	Description
1	A2-S225-034	1	Flap filter
2	A0-A016-001	1	Basket support wheel
3	A0-E055-024	1	Multipole wall type connector
4	A0-E011-018	4	Limit switch variable length
5	A0-E011-022	1	Switch, limit momentary
6	A0-E014-001	1	Micro switch





Parts List

Item	Part No.	Qty.	Description
1	A0-E011-022	1	Switch, limit momentary
2	A0-A016-002	4	Wheel rubber
3	A0-M009-078	2	Sleeve wheel bush conex A

Parts List

Item	Part No.	Qty.	Description
4	A0-A007-011	4	Plummer block Housing
	A0-A007-025	4	Locating Rings set
	A0-A006-145	4	Sleeve
5	A0-M011-026	2	Drive shaft basket
6	A0-E023-012	1	Proximity sensor
7	A0-E008-471	1	Helical geared motor
8	A0-A051-019	1	Double chain
9	A0-M001-031	1	Double sprocket
10	A0-M001-032	1	Double sprocket



Parts List

Item	Part No.	Qty.	Description
1	A0-E011-022	1	Switch, limit momentary
2	A0-A016-002	4	Wheel rubber
3	A0-M009-078	2	Sleeve wheel bush conex A

Parts List

Item	Part No.	Qty.	Description
4	A0-A007-011	4	Plummer block Housing
	A0-A007-025	4	Locating Rings set
	A0-A006-145	4	Sleeve
5	A2-S225-035	4	Support bearing wheel assembly
6	A0-M011-026	1	Drive shaft basket




Parts List

Item	Part No.	Qty.	Description
1	A0-A013-002	1	Lock, Panel control right
2	A0-E007-007	1	Key board fiber
	A0-E007-004	1	EDG Dryer control
3	A0-E032-022	1	Emergency stop button, Turn to RELEASE, metal ring (Head)
	A0-E032-035	1	Emergency stop Button (red)
	A0-E032-023	1	Emergency stop contactor base
4	A0-E035-021	1	Pilot light
5	A0-E032-009	1	Push buttons (Green)
6	A0-E032-002	1	Push buttons (Red)
7	A0-E033-012	1	Selector switch
8	A0-P004-001	1	Regulator
9	A0-TSE01-029	1	Solenoid valve
10	A0-E059-005	2	Lamp, indicator, red





Parts List

Item	Part No.	Qty.	Description
1	A2-S225-007	1	Door dryer, right
2	A2-S225-008	1	Door dryer, left
3	A0-A036-004	3	Magnet catch (Dryer)
4	A2-S225-018	1	Door lint drawer filter
5	A0-A036-004	1	Magnet catch (Dryer)
6	A0-E027-010	1	Temperature probe, EDG
7	A0-E016-005	1	Thermostat
8	A0-E016-011	1	Thermostat






Parts List

Item	Part No.	Qty.	Description
1	A0-P003-030	4	Aie cylinder
2	A0-A020-003	1	Ball valve, 1/2"
3	A0-P008-002	4	Quick Exhaust valve
4	A0-TSE01-063	1	Motor
5	A2-S225-033	1	Exhaust duct



Parts List

Item	Part No.	Qty.	Description
1	A0-P003-030	4	Air cylinder
2	A2-S225-018	1	Door lint drawer filter
3	A0-TSE01-063	1	Motor
4	A0-P005-120	1	Diaphragm valve



Parts List

Item	Part No.	Qty.	Description
1	A2-S225-028	1	Rear panel assembly, top
2	A0-E018-003	1	Valve,gas
3	A0-E020-001	2	Ignition control
4	A0-E040-008	1	Solenoid water valve
5	A0-E019-001	1	Spark Probe
6	A0-E018-003	1	Valve,gas
7	A0-A089-002	3	Gas Burner Tube,
8	A0-E014-001	1	Micro switch